

Quick Report

1. In the Map View, select the vehicle/device
2. Click on the “Quick Report” icon on the toolbar



Or

1. In the Map View, select the vehicle/device to locate. Click on the blue arrow
2. An information bubble will appear next to the selected vehicle
3. Click on “Quick Report”
4. A new window will appear
5. Select the type of report desired

* The icon  will appear if the device is sending an invalid GPS message and the last valid signal will be displayed

