

CATEGORY ARCHIVES: **MAP VIEW**

Locate Now

1. In the Map View, select the vehicle/device to locate
2. Click on the “Locate Now” icon on the taskbar.



Or

1. In the Map View, select the vehicle/device to locate. Click on the blue arrow
2. An information bubble will appear next to the selected vehicle
3. Click on “Locate Now” button

To access Google maps and get a satellite view of the location click on the latitude and longitude coordinates on the information bubble.



Enable Starter

1. In the Map View, select the vehicle/device
2. Click on the “Enable Starter” icon on the Toolbar



Or

1. In the Map View, select the vehicle/device to locate. Click on the blue arrow
2. An information bubble will appear next to the selected vehicle
3. Click on “Enable Starter” button



Disable Starter

1. In the Map View, select the vehicle/device
2. Click on the “Disable Starter” icon on the Toolbar



Or

1. In the Map View, select the vehicle/device to locate. Click on the blue arrow
2. An information bubble will appear next to the selected vehicle
3. Click on “Disable Starter”



Buzzer On

1. In the Map View, select the vehicle/device
2. Click on the "Reminder On" icon on the toolbar



Buzzer Off

1. In the Map View, select the vehicle/device
2. Click on the "Reminder Off" icon on the toolbar




Emergency Enable

1. In the Map View, select the vehicle/device
2. Click on the “Emergency Enable” icon on the toolbar



Schedule Command


1. In the Map View, select the vehicle/device
2. Click on the “Schedule Command” icon on the toolbar
3. A new window will appear
4. Fill out the required information and click “OK”



Batch Command


1. Click on the "Batch Command" icon on the toolbar
2. A new window will appear
3. Click on "Upload CSV" select the file and click on "Open"

The .csv file should contain the follow columns in this order: Unit Name, IMEI and Serial Number. Up to 100 records per file.




Repo Command

1. In the Map View, select the vehicle/device
2. Click on the "Repo Mode" icon on the toolbar
3. A new window will pop-up. Fill out and review the information
4. Click on "Confirm Repo"



Or

1. Locate your vehicle/device.
2. Click on your vehicle/device in the map. A new information bubble will appear. Click on "Repo"
3. Follow steps 3 and 4




Quick Report



1. In the Map View, select the vehicle/device
2. Click on the "Quick Report" icon on the toolbar



Or


1. In the Map View, select the vehicle/device to locate. Click on the blue arrow
2. An information bubble will appear next to the selected vehicle
3. Click on "Quick Report"
4. A new window will appear
5. Select the type of report desired

* The icon  will appear if the device is sending an invalid GPS message and the last valid signal will be displayed




Transfer Device

1. In the Map View, select the vehicle/device
2. Click on the "Transfer Command" icon on the toolbar
3. A new window will appear. Select between "Transfer inside my account" or "Transfer outside my account"
4. Select the group to transfer the device
5. Click on "Transfer"
6. A new window will appear for review. Click on "Confirm Transfer"



Or

1. Locate your vehicle/device.
2. Click on your vehicle/device in the map. A new information bubble will appear. Click on "Transfer"
3. Follow steps 3 through 6



Transfer Management

1. Click on the “Transfer Management” icon on the toolbar to see all transfer history.

